From:	Winlink@groups.io on behalf of NOYWB
То:	Winlink@groups.io
Subject:	[Winlink Programs Group] Windows Sound level setting for each application
Date:	Sunday, April 18, 2021 07:51:06

After years of fumbling through the menus to adjust the Windows 10 Sound sliders every time I changed digital modes apps,

I discover that each application has its own level setting.

I

Go to Settings | Sound | Advanced sound options | App volume and device preferences. You have to open each app to make it visible. Change Default to the specific sound device.

Notice that the other apps that share the same device are grayed out. The first app opened is in control, and can be adjusted, until it is closed.

These are a percentage of the Master level setting, so set the Master volume once, and leave it alone.

https://www.technipages.com/change-volume-specific-apps-windows-10

djust the master volume to change all	Output
ounds. You can adjust volume for pecific apps and system sounds as a	Speakers (High Defi $$
vercentage of the master volume. Master volume	Input
dŵ 75	Aux (High Definition $ \sim $
App Volume System sounds	Output Input Default ~
48 48	Default ~
ARDOP_Win Virtual TNC Ver: 1.0.2.5	Speakers (USB PnP So $$
40 50	Microphone (USB PnP $$
fldigi ver4.1.18.16 / RigCAT - IC-7000 - N0YWB	Speakers (USB PnP So $$
40 85	Microphone (USB PnP $ \lor $
Mozilla Firefox	Default
40 68	Default ~
VARA HF v4.4.3	Speakers (USB PnP So V
40 50	Microphone (USB PnP V

.